



# Build your own wedi Steam Room

Using wedi Vapor 85 Building Panels and more...

For steam rooms with heaviest water and vapor exposure, the wedi Vapor 85 line is both a clean and fast to install building panel type construction system. It also provides integrated water and vaporproofing throughout the entire assembly system. Below you'll find a list of items to create your own wedi Steam Room!

- wedi Fundo Ligno Shower Base
- wedi Vapor 85 Building Panel
- wedi Sealant 620
- wedi Fastener Kit
- wedi Vapor 85 Fastener Patch Kit
- wedi Putty Knife
- Subliner Dry Sealing Tape, Inside Corner
- Subliner Dry Sealing Tape, Outside Corner
- wedi Subliner Dry Waterproof Sealing Tape



For more information contact Peter Beckmann at +61 437 678 459, by email at [Peter.Beckmann@wedi.com.au](mailto:Peter.Beckmann@wedi.com.au) or visit our website at [www.wedi.com.au](http://www.wedi.com.au).