

wedi Sealant Comparison: wedi 610 adhesive sealant vs. wedi 620 sealant

There are a few differences between wedi 610 adhesive sealant and wedi 620 sealant. The below chart will explain the common comparisons so you know which application is best for each product!

Original wedi 610 adhesive sealant	New wedi 620 sealant
wedi 610 is a flexible sealant and construction adhesive that creates strong connections between wedi assembly parts without additional tape reinforcement.	wedi 620 is a flexible sealant offering vapour tight performance. It is used with wedi sealing tape to create a strong connections in wedi assemblies.
Used for standard wedi shower installations with the wedi Fundo Primo, wedi Fundo Ligno and wedi Fundo Riolito neo. This would include the drain assembly, building panel installation and the channels, seams and fasteners.	Used for wedi Vapor 85 steam shower installations. They are installed using the wedi 620 sealant between assembly components. Use to waterproof and affix wedi sealing tape over seams and fastener points.
Used for pre-made benches and benches constructed from 50 mm wedi Building Panels.	For use with all wedi Subliner Dry products (includes wedi inside/outside corner sealing tape, wedi waterproof sealing tape, wedi Vapor 85 patches for fastener locations, and wedi Subliner Dry mats for seams and overlaps). Note: Tile adhesive is also used in the installation of wedi Subliner Dry. See installation instructions for more information.



Indispensable in regular wedi shower assemblies to seal and reinforce seams and connections, as well as waterproof fastener points. No additional taping needed!



Indispensable in combination with wedi Vapor 85 and wedi Subliner Dry



For more information

contact Peter Beckmann at +61 437 678 459, by email at Peter.Beckmann@wedi.com.au or visit our website at www.wedi.com.au.